
LG VX3100 Battery Replacement

Written By: Tyler




INTRODUCTION

Have a **dead** battery? Then replace it with a **new** battery by following this simple repair guide:

PARTS:

- LG VX3100 battery (1)

Step 1 — Battery





- Turn off the cellphone by pressing down on the red "END" button for 3 seconds.
- Flip cellphone over and press up on the gray sliding mechanism towards the top of the phone. At the same time, pull on the large silver battery and it should come right off.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-05 08:47:03 AM.

